



## Electronica EL400 Display Reset

Congratulations on the purchase of your Electronica EL400 series kit. This article addresses how to reset your EL400 display.

Turn DRO off / then turn it back on.

< *push the “wrench” button on bottom left to enter setup mode* >

SELEcT

< *push the “X” button* >

LinEAR

< *push the #2 button until the display reads...* >

oEm mod

< *push the enter button* >

EntEr LoC

< *push 35726 followed by the enter button* >

2 AXiS      3 AXiS / 4 AXiS / 1 AXiS / 2 AXiS

< *press the #6 key to change values* >

< *push the #2 key* >

miLL      miLL / LAthE / Edm / SimPLE

< *press the #6 key to change values* >

< *push the #2 key* >

oPt oFF      oPt oFF / Opt on

< *push the #2 key* >

SAv ChG

< *push the enter button* >

rSt dEF

< *push the enter button* >

**NOTE: The display will not react instantly. Give the display time to react.**

In a moment, it will read < in Prog > The reset will take several minutes to complete. When the reset is complete, the display will be back on the home ABS screen.